

# User manual of DMV 5000 intelligent digital pressure indicator



## Notes



### **Dangerous**

Attention Risk of Electronic Shock

When we connect the power, please do not touch AC wire to avoid shock



### **Warning**

This instrument is an open device, so when to make applications for the risk, such as: they will cause harm and damage to other equipment, make sure to install security devices to automatic devices.

- You should carefully check the wiring is correct before instrument power supply terminal, to avoid serious damage to instrumentation.
- Make sure to wiring, signal devices have access to correct and appropriate terminal; Please do not use any left terminal.
- This instrument is an open case, to be installed in a dust, humidity, shock and strong shocks from distribution box; Do not alter, disassemble the instrument.
- The instrument should be installed as far as possible away from the high voltage and electromagnetic interference region, to ensure stable and reliable instrument.
- Do not touch the meter power terminals or repair the body to avoid electric shock.
- Please avoid this harsh environment of the instrument:  
The dust and corrosive gases over the place;  
High humidity and high radiation areas;  
Strong vibration and strong impact of workplace.

## Functional and technical specifications

DMV 5000 series intelligent digital pressure indicator is the production company to develop new industrial control instruments, which can completely replace the imported products of similar high-grade pressure indicator. Highly cost-effective, and can adapt to volatile network occasion. The pressure indicator appearance, complete functions, interference with excellent performance to ensure reliability of the system work.


- ☆ Figures show bits: double-color 4;
- ☆ Within the resolution: 32000;
- ☆ External Resolution:  
0001, 0002, 0005, 0010 Panel Switch (power failure protection setting of  $\geq 40$  years);
- ☆ Nonlinear:  
0.05%  $\pm 1$  word, 0.1%  $\pm 1$  word, 0.2%  $\pm 1$  word, 0.5%  $\pm 1$  word;
- ☆ Pressure Range: programmable options;
- ☆ Engineering units: MPa, psi, bar, kgf/cm<sup>2</sup> programmable options;
- ☆ Decimal point location: Programmable;
- ☆ Alarm settings: Two programmable alarm settings;
- ☆ Relay contact output: 250VAC, 5A;
- ☆ Linear output:  
0 ~ 10mA, 0 ~ 20mA, 4 ~ 20mA, 0 ~ 5V, 1 ~ 5V, 0 ~ 10V programmable options;
- ☆ Instrument Communication: RS485 interface (optional);  
Mailing address: 0001 ~ 0255;  
Communication baud rate 2400bps, 4800bps, 9600bps, 19200bps, 38400bps;
- ☆ Power supply: 85 ~ 265VAC;
- ☆ Ambient temperature: 10 °C ~ +85 °C;
- ☆ Humidity:  $\leq 80\%$  RH;
- ☆ Continuous trouble-free working time:  $\geq 50000$  hours.

# DMV 5000 User Instructions

Welcome to use DMV 5000 Series Intelligent pressure indicator from Bagsik Sp. zo.o. This manual details the functions of the form and use, please read carefully before use!

## 1. Instrument panel

### 1.1 The instrument panel diagram:



### 1.2 Indicator

DMV 5000Series Intelligent pressure indicator on the left panel contains two alarm lights, a calibrated light and four pressure unit lights on the right, its functions as follows:


- 1) The first alarm indicator AL1: long light alarm light, no alarm light goes out;
- 2) The second alarm indicator AL2: long bright alarm light, no warning light goes out;
- 3) Calibration status indicator CAL: calibration of pressure indicator, the light starts flashing, the calibration end then the light off;
- 4) The unit of pressure indicator: programmable selection of the corresponding pressure, the corresponding length indicator light

### 1.3 Button

DMV 5000Series Intelligent Pressure indicator consists of four function keys, respectively, SEL function keys, shift key, to increase and decrease keys function keys as follows:

- \* **SEL** Function button: used to access the programming menu and set the points and long by two kinds of manipulation by way of ;
- \* **<** Shift button;
- \* **∨** Reduction button;
- \* **∧** Increase button;
- \* **SEL+ <** Clear button: while pressing the 2 keys 5 seconds to restore the pressure to zero;
- \* **SEL+ ∨** Restore button: the pressure value after the error is cleared, pressing two keys simultaneously for more than 5 seconds to restore pressure to zero;
- \* **SEL+ ∧** Calibration key: see page 10 of the calibration instructions;

## 2. Instrumentation wiring




### Alarm Terminals Description:

First Alarm Terminal Blocks	NC	Relay normally closed terminal
	C	Relay public-side
	NO	Relay normally open terminal
Second Alarm Terminal Blocks	NC	Relay normally closed terminal
	C	Relay public-side
	NO	Relay normally open terminal

### Transducer Terminals Description:

Sensor Signal	S+	Sensor signal S+
	S-	Sensor signal S-
Sensor Excitation	E+	Sensor Bridge Power E+
	E-	Sensor Bridge Power E-
Sensor Calibration	Cal1	80% FSO Calibration 1
	Cal2	80% FSO Calibration 2

## 3. Overall dimension



## 4. Parameter setting


### 4.1 The three working states of pressure indicator :

DMV 5000series pressure indicator, there are three working states: "Measure working state", "Fast set-up working state" and the "System set-up working state". After power on both the pressure indicator into the "Measure working state".


### 4.2 Fast set-up working state operating :




Boot into measure working state, click **SEL** key to enter the fast set-up working state. This state can set the first and second alarm values. PV window display alarm character; SV window display set-up alarm value, digit shines through the **<** **∇** **∧** key to set the desired alarm value. Setup is complete, click **SEL** key of 5 seconds to return to Measure working state.




### 4.3 System set-up working state operating:



From the measure working state by clicking **SEL** key into the fast set-up working state. (SV window last digit flashing). In the fast set-up working state press **SEL** key more than 5 seconds into the system set-up working state.




### 4.3.1 Pressure unit setting:




By clicking **v** and **^** key select the desired unit of pressure. Click **SEL** key to confirm. Corresponding pressure unit lights lit, and enter the decimal place setting item.

### 4.3.2 Decimal place setting:




By clicking **v** or **^** key to select the desired decimal place. Click **SEL** key to confirm. And enter the pressure range setting item.

### 4.3.3 pressure range setting:




By clicking **v** or **^** key to select the desired pressure range. Click **SEL** key to confirm. And enter the display resolution setting item.

### 4.3.4 display resolution setting:





By clicking **v** or **^** key select the display resolution of pressure. ( Recommended selection 0010 ). Click **SEL** key to confirm. And enter the first alarm pressure value setting item.

#### 4.3.5 First alarm pressure value setting:



By clicking **<** **∇** **▲** key to set the first alarm pressure value. Click **SEL** key to confirm. And enter the first alarm way setting item.

#### 4.3.6 First alarm way setting:




"0001" way code Note: When measuring the pressure is lower than the alarm pressure value. AL1 alarm indicator lights. 7, 8 terminals conduction; 8, 9 terminals disconnect. When measured pressure value is higher than the alarm pressure value, AL1 alarm indicator is off. 7, 8 terminals disconnect; 8, 9 terminals conduction.

"0002" way code Note: When measuring the pressure is lower than the alarm pressure value, AL1 alarm indicator is off. 7, 8 terminals disconnect; 8, 9 terminals conduction. When measured pressure value is higher than the alarm pressure value, AL1 alarm indicator lights. 7, 8 terminals conduction; 8, 9 terminals disconnect.


By clicking **∇** or **▲** key select the first alarm way. Click **SEL** key to confirm. And enter the second alarm pressure value setting item.

#### 4.3.7 First alarm pressure hysteresis band setting:





By clicking **<** **∇** **▲** key to set First alarm pressure hysteresis band. Click **SEL** key to confirm. And enter the second alarm pressure value setting item.

#### 4.3.8 Second alarm pressure value setting:



By clicking **<** **∇** **▲** key to set the second alarm pressure value. Click **SEL** key to confirm. And enter the second alarm way setting item.

#### 4.3.9 Second alarm way setting:




"0001" waycode Note: When measuring the pressure is lower than the alarm pressure value, AL1 alarm indicator lights. 10,11 terminals conduction; 11, 12 terminals disconnect. When measured pressure value is higher than the alarm pressure value, AL1 alarm indicator is off. 10,11 terminals disconnect; 11,12 terminals conduction.

"0002" way code Note: When measuring the pressure is lower than the alarm pressure value, AL1 alarm indicator is off. 10,11 terminals disconnect; 11,12 terminals conduction. When measured pressure value is higher than the alarm pressure value, AL1 alarm indicator lights. 10,11 terminals conduction; 11,12 terminals disconnect.

By clicking **∇** or **▲** key select the first alarm way. Click **SEL** key to confirm. And enter the second alarm pressure value setting item.


#### 4.3.10 Second alarm pressure hysteresis band setting:



By clicking **<** **∇** **▲** key to set First alarm pressure hysteresis band. Click **SEL** key to confirm. And enter the Calibration way setting item.




#### 4.3.11 Calibration way setting:




By clicking **v** or **^** key select the Calibration way. (Recommended selection 0000). Click **SEL** key to confirm. And enter into the output signal setting item.

#### 4.3.12 Output signal setting:




By clicking **v** or **^** key select the output signal. Click **SEL** key to confirm. If the pressure indicator has a communication function, then enter the key lock setting item (see 4.3.15). If the pressure indicator has a communication function, then enter the communication address setting item.

#### 4.3.13 Communication address setting (Optional):




By clicking **<** **v** **^** key select the communication address. Optional address: 0001 ~ 0255. Click **SEL** key to confirm. then enter the Communication baud rate setting item.

#### 4.3.14 Communication baud rate setting(Optional):



By clicking **▼** or **▲** key select the Communication baud rate. ( Recommended selection 9600 ). Click **SEL** key to confirm. And enter the key lock setting item.

#### 4.3.15 Key lock setting:



By clicking **▼** or **▲** key to select whether the indicator key lock, Click **SEL** key to confirm. And back enter the pressure units setting item(back 4.3.1).








#### 4.4 System setting menu table :

Item	Name	Options	Explain	Initial V alue
<b>unit</b>	Pressure Units Setting	psi bar MPa kgf/cm <sup>2</sup> off	Choice of four pressure units and provide close pressure unit options.	By matching mass Sensor range Or According to the user Demand set
Unit				
<b>dot</b>	Decimal Place Setting	----. ---.- --.-. -.-.-	Decimal Position Setting	By matching mass Sensor range Or According to the user Demand set
dot				
<b>8888</b>	Pressure Range Setting	1000、 1500、 2000 2500、 3000、 3500 4000、 5000、 6000 7000、 7500、 8000 9999	According to supporting sensor range, the pressure unit and decimal position setting.	By matching mass Sensor range Or According to the user Demand set
RN				

(To be continued on next table)

#### 4.4 System setting menu table :

(Connected to the before table)

Item	Name	Options	Explain	Initial Value
 dv	Display Resolution Setting	0001 0002 0005 0010	0001: the end of the display:0 ~ 9 0002: the end of the show:0,2,4,6,8 0005: the end of the show:0,5 0010: the end of the show only: 0	0010
 AL1	First Alarm Value Setting	0000 ~ 9999	According to user requirements setting	80% RN
 SEL1	First Alarm Way Setting	0000 0001 0002	0000: Turn off alarm 0001: Pressure value less than setting Alarm 0002: Pressure value more than setting Alarm	0002
 DLY1	First Alarm Hysteresis Band Setting	0000 ~ 0200	According to user requirements setting	0000
 AL2	Second Alarm value Setting	0000 ~ 9999	According to user requirements setting	RN 20 %
 SEL2	Second Alarm way Setting	0000 0001 0002	0000: Turn off alarm 0001: Pressure value less than setting Alarm 0002: Pressure value more than setting Alarm	0001
 DLY2	Second Alarm Hysteresis Band Setting	0000 ~ 0200	According to user requirements setting	0000
 E_SC	Calibration Way Setting	0000 0001	0000: Automatic calibration method 0001: Manual calibration method	0000
 OUT	Output Signal Setting	0~5V 1~5V 0~10V 0~10mA 0~20mA 4~20mA	Provide 6 types standard output signal users to demand their own programming setting.	According to the user Demand set
 Addr	Communication Address setting (Optional)	0001 ~ 0255	Provide 1~255 address programmable setting (optional)	0001
 bps	Communication Baud Rate Setting (Optional)	2400 4800 9600 19200 38400	Provide 5 types standard baud rate programmable setting (optional)	9600
 LCK	Key Lock Setting	0000 0001	0000: Key not lock, can modify the parameters 0001: key lock, can not modify the parameters	0000

## 5 Pressure indicator calibration operation

### 5.1 Automatic calibration of pressure indicator operation:

Automatic calibration before the unlock key(the "LCK" parameter set "0000"), and calibration methods foautomatic calibration (the"E\_SC" parameter set "0000").

Guarantee melt pressure transducer is working in environment temperature and working pressure is zero.

The melt pressure transducer and intelligent pressure indicator according to the instruction to connect well,and also connected the 220VAC power supply. Entered measurement instrument self-test state,then can be automatically calibrated, the concrete operation is as follows:


Click down the **SEL** key while you click the **▲** key , PV window display **2E80** SV values in the window display "from 2000 to6000" between, this value for the pressure transducer zero-point code value, while theCAL calibration-light flashes.

After about 5 seconds, PV window shows **FU88** or **FU82**. SV values in the window display "16,000 ~ 25,000" between(ten thousand's place in PV window at the end of display). This number is the pressure transducer 80% range of thecode values. Waiting in the calibrationprocess of **SEL** key can not let go.

After about 5 seconds, PV window shows **0000** Pressure transducer calibration information has been written to indicator at this time at the endof the automatic calibration operation, calibration light goes out. Throughout the calibrationprocess **SEL** key and do not let go. (If this process does not show that the 80% range value, or this value error is too large.please re-operationof the automaticcalibration, and check either the indicator range settings are correct or pressure transducer and indicator connection are correct.)

Then, release the **SEL** key, the indicator isinto the Fast set-up working state. Click the **SEL** key twice, the indicator will be back to measuring working state


Automatic calibration operation is complete.







## 5.2 Manual calibration of pressure indicator operation:

This function is for pressure transducer without calibration signal or calibration signal error too large that can not adjust. Before manual calibration we should unlock the key (the "LCK" parameter set "0000"), and calibration methods for the manual calibration (the "E\_SC" parameter set "0001"). Guarantee pressure transducer probe-pressure is zero.

First, installing the pressure transducer to the provide standard pressure source device. Then connect the pressure transducer and pressure indicator according to the instruction to connect, and then connected the 220V AC power. Indicator power-on self - test into measure working state, then in accordance with the operation entering to system parameter setting state (4.3 - page 3). The range is set to the corresponding pressure transducer range, and then can be manually calibrated, the concrete operation is as follows:

① Press the **SEL** key while you click the **▲** key, PV window display  SV window value should be between "2000 ~ 5000", this value is the pressure transducer zero-point's code value, while the CAL calibration-light flashes. click the **▲** key to confirm the zero-point code. In the calibration process pressing the **SEL** key can not release.

② After confirming zero-point code, PV window display  then through a standard pressure source to the pressure sensor to full pressure range, then PV window display  or , SV window value should be between "16,000 ~ 32,000" (ten thousand's place in PV window at the end of display), waiting for the value of relative stability, then click the **▲** to confirm and the calibration light goes out. PV window display the value of a standard source to provide of the pressure value. Release the **SEL** key and unload pressure to zero, then the indicator will be into the fast set-up working state. Click the **SEL** key twice, indicator will be back to measure working state. Manual calibration operation is complete. (If the PV window display the standard pressure value error is too large, return to step ① re-operation.)



## 6 Measure workingstate

### 6.1 Measure working state

PV window display the pressure measurement value, On the right correspond presure units light long SV window shows the first alarm pressure value. Normal measure working stateon the leftalarm and calibrationlight is off, when the test pressur value is lower or higher than the alarm pressure value, the AL2 or AL1 alarm lights turn on; wh en the test pressurevalue is to restore Normal, theAL2 or AL1 alarm lights turn off.

### 6.2 Measure working state drift - clear operation:

First automatic calibration operation (section5.1 on page10). After time, if there are temperature drift or time shift, you can hold down the **SEL** key at the same time click **<** key to clear the current drift value.if clear wrong ,you can hold down the**SEL** key and**∨**key, more than 5seconds to restore zero.

## 9 Service

- ① Open the package, Please check the product whether it meets your requirements packaging, products if there is any damage, if found in error. Please contact us.
- ② This product is a precision measuring indicator. Can not be beat, pounding, powerful treatment. Improper operation due to man-made damage caused by products not under warranty.
- ③ The following are not covered under warranty:
  - Not in accordance with the instructions proper installation, man-made product damage;
  - Unauthorized users of the product for repairing or reconstruction;
  - By irresistible external forces caused by damage to the product;
  - Unclear or missing product label, the product looks seriously damaged.
- ④ If there is any problem when you are using our products, Please keep defective product, contact with our company, explain the phenomenon of failure and use of the environment, our company will provide timely technical support. Do not unauthorized repair.



#### **Czujniki ciśnienia masy tworzyw sztucznych.**

CDA - od 50 -1400 bar - sygnał 3.33mV/V  
CDAI - sygnał analogowy 0-10 V, 4-20mA  
CDTA - zintegrowana termopara, sygnał 3.33mV/V  
CDTAI - zintegrowana termopara, sygnał analogowy



#### **Akcesoria:**

Wtyczki do czujników ciśnienia, 6 - PIN.  
Wtyczki do czujników temperatury.



#### **Akcesoria:**

Kable do czujników ciśnienia, ekranowane z opłotem z włókna węglowego.  
- Gotowy komplet z wtyczką do ciśnienia - 3m  
- Według specyfikacji klienta z szpuli na metry



#### **Bezpieczniki ciśnienia seria BP:**

- gwint 1/2"  
- zakres wg specyfikacji klienta



#### **Zestaw do czyszczenia gwintów pod czujniki ciśnienia oraz temperatury.**

**Tuleje redukcyjne**  
- M16, M18x1.5, M24